




Dogtra-Europe


Immeuble Le Vauban
Parc d'activités de La Verrière
4 rue de Panicalé
78320 La Verrière, France
TEL: +33 (0) 130 62 65 65
FAX: +33 (0) 130 62 66 11
E-mail: info@dogtra-europe.com

Notice d'initialisation pour Dogtra RB1000 / RB1002




Interrupteur à bascule GR/OR

1. Commencer l'initialisation avec l'émetteur étant allumé et le collier-récepteur éteint. Sur le devant de l'émetteur se trouve l'interrupteur à bascule **GR/OR**. Positionner cet interrupteur sur "**GR**" pour initialiser le collier-récepteur **VERT**. Positionner l'interrupteur sur "**OR**" pour initialiser le collier-récepteur **ORANGE**.



2. Placer le point rouge magnétique situé au dos de l'émetteur sur celui situé sur le collier-récepteur. Maintenez-les ainsi pendant 5 secondes. Lorsque le voyant LED situé sur le collier-récepteur commence à clignoter rapidement, séparer les deux points rouges.



Bouton *RUN/POINT* et bouton *POINT* sur le devant de l'émetteur


3. Maintenez le bouton *RUN/POINT* et le bouton *POINT* situé sur l'avant de l'émetteur appuyé simultanément pendant 3 secondes, ou jusqu'à ce que le voyant LED du collier-récepteur clignote plus lentement.

Le travail d'initialisation est maintenant terminé.




Dogtra-Europe
Immeuble Le Vauban
Parc d'activités de La Verrière
4 rue de Panicalé
78320 La Verrière, France
TEL: +33 (0) 130 62 65 65
FAX: +33 (0) 130 62 66 11
E-mail: info@dogtra-europe.com


Code setting guide for Dogtra RB1000 / RB1002



1. Start with the receiver/collar turned off and the transmitter turned on.
On the front of the transmitter there is a GR/OR toggle switch. Set this toggle switch on the “**GR**” position to synchronize the transmitter with the **GREEN** collar/receiver. Set the toggle switch on the “**OR**” position to synchronize the transmitter with the **ORANGE** collar/receiver.



2. Place the red dot on the back of the transmitter against the red dot on the Green or Orange collar/receiver. Hold the two red dots together for several seconds, until the green LED on the receiver/collar starts to blink rapidly, and then separate the two red dots.



3. Hold the *RUN/POINT* button and the *POINT* button on the front of the transmitter simultaneously down for 3 seconds or until the rapid green blink of the LED on the receiver/collar resumes a slower pace. The code setting work is now completed.